



To Power Supply



1

2

5

4

3

7

6

TEFLON TAPE THREADS
Do Not Overtighten

DRAIN VALVE

Flow Meter should be placed on the Outlet Side. Note the *flow direction arrow* on the meter body.